

AA Composites - 0444568646

RiverTable Instructions & Info

3:1 by Weight

RiverTable is an older resin that was made to make RiverTables, it has been a customer favourite for many years especially since the RiverTable industry has grown

Mix 3 parts A to 1 Part B by weight. Mix resin and hardener together, the resin will go cloudy - keep mixing until resin goes back to clear *always mix by hand*. Make sure all of the product has been mixed, including scraping the sides of the mixing container. Pour resin and allow to cure.

Depth of Resin: RiverTable Resin pour depth is minimum 30mm depth and maximum 50mm depth.

Setting time of Resin: Working time: 1 ½ Hours
Initial Cure: 24 Hours
Full Cure: 10 Days

*Please note that the resin times are based on 25°C lab tested results and will vary on depth of pour and temperature.

Resin will not set below 10°C, and will take longer in a cooler environment, make sure on cooler days that the resin is in the sun or near heat, you can warm the bottles in hot tap water before pouring to allow the resin to heat up a bit.