

AA Composites - 0444568646

Ultra / Super Clear Instructions & Info

2:1 by Volume

Ultra & Super Clear are some of our older resins - ultra clear has been made for 30 years! These are multi purpose resins. The difference between Ultra Clear and Super Clear is that Ultra Clear has a gloss finish whereas Super Clear is a matte finish.

Mix 2 parts A to 1 Part B by volume. Mix resin and hardener together, the resin will go cloudy - keep mixing until resin goes back to clear *always mix by hand*. Make sure all of the product has been mixed, including scraping the sides of the mixing container. Pour resin and allow to cure.

Depth of Resin: Ultra Clear and Super Clear can be used as a coat or can be poured to 13mm

Setting time of Resin: Working time: 45 Minutes
Initial Cure: 12 Hours
Full Cure: 3 Days

*Please note that the resin times are based on 25°C lab tested results and will vary on depth of pour and temperature.

Resin will not set below 10°C, and will take longer in a cooler environment, make sure on cooler days that the resin is in the sun or near heat, you can warm the bottles in hot tap water before pouring to allow the resin to heat up a bit.